# Frequency Modulation

#### Department of Electronics and Communication Enginnering CUTM

# Angle Modulation

- Angle modulation is defined as the process in which the angle of the carrier (either frequency or phase) is varied linearly according to the message signal.
- There are two types of angle modulation:


Frequency ModulationPhase Modulation

Equation:  $S_{FM}(t) = A_c \cos[2\pi f_c t + 2\pi k_f \int_{0}^{t} m(t)dt] \xrightarrow{K_f \text{ is the frequency sensitivity of frequency modulator (Hz/ volt)}}{S_{PM}(t) = A_c \cos[2\pi f_c t + k_p m(t)]} \xrightarrow{0} K_p \text{ is the phase sensitivity of the modulator (radians/volt)}}$ 

### **Frequency Modulation**


• Carrier signal = 
$$A_c \cos(2\pi f_c t + \phi)$$

$$Angle = \theta(t) = 2\pi f_c t + \phi$$
$$2\pi f_c t \to rad$$



- Instantaneous frequency f<sub>i</sub>(t)=f<sub>c</sub>+k<sub>f</sub>m(t)
- If m(t)=0, then no modulation i.e.  $f_i(t)=f_c$
- K<sub>f</sub> specifies the amount of frequency change in the carrier signal for 1 volt change of the message signal.
- $K_f = 50 \text{ kH}_z/\text{volt (given)}$
- When m(t)= 0 volt, fi=fc
- When m(t)= 5 volt, then  $f_i = f_c + 50 \text{ kHz/volt x 5 volt} = f_c + 250 \text{ kHz}$
- When m(t)= -5 volt, then  $f_i = f_c 50 \text{ kHz/volt x 5 volt} = f_c 250 \text{ kHz}$

#### • Summary



- In FM, message signal voltage variation are converted to an carrier signal frequency variation so it is also called as voltage to frequency conversion
- For m(t) =  $A_m Cos 2\pi f_m t$  or  $A_m Sin 2\pi f_m t$

• Maximum possible frequency of the resulting signal

$$f_{max} = f_c + k_f A_m$$

• Minimum possible frequency of the resulting signal

$$f_{min} = f_c - k_f A_m$$

• Maximum possible frequency deviation => $\Delta f = |Max[k_f m(t)]|$ 

$$\Delta f = |Max(k_f m(t))|$$
$$\Delta f = K_f A_m Hz$$
$$f_{max} = f_c + \Delta f$$
$$f_{min} = f_c - \Delta f$$

Total frequency swing of the resulting FM signal is  $f_{max}$ - $f_{min}$ =2 $\Delta f$ 

## General Expression of FM signal

- Carrier signal =  $C(t) = A_c Cos[2\pi f_c t + \varphi]$
- $C(t)=A_cCos[\Theta(t)]$  Where  $\Theta(t)=2\pi fct+\varphi$

$$\frac{d\theta(t)}{dt} = 2\pi f_c$$

• General expression of FM signal is

 $S_{FM}(t) = A_c \text{Cos}[\theta_i(t)]$ 

•  $\Theta_i(t)$  = Instantaneous angle

• If 
$$\frac{d\theta(t)}{dt} = 2\pi f_c$$
  
 $\frac{d\theta_i(t)}{dt} = 2\pi f_i$   
 $\theta_i(t) = 2\pi \int f_i dt$   
 $\theta_i(t) = 2\pi \int [f_c + k_f m(t)] dt$   
 $S_{FM}(t) = A_c \cos[2\pi f_c t + 2\pi k_f \int_0^t m(t) dt]$   
 $\theta_i(t) = 2\pi f_c t + 2\pi k_f \int_0^t m(t) dt$ 

## Single tone FM

• Assume  $m(t)=A_m Cos 2\pi f_m t$ 

$$\int m(t)dt = \int \left(A_m \cos 2\pi f_m t\right)dt = \frac{A_m \sin 2\pi f_m t}{2\pi f_m}$$
$$S_{FM}(t) = A_c \cos\left[2\pi f_c t + \frac{2\pi k_f A_m \sin 2\pi f_m t}{2\pi f_m}\right]$$

$$S_{FM}(t) = A_c \operatorname{Cos}[2\pi f_c t + \beta \sin 2\pi f_m t]$$

 $\beta$  is the modulation index of FM

$$\beta = \frac{K_f A_m}{f_m} = \frac{\Delta f}{f_m}$$