

Rocket engine nozzle

A **rocket engine nozzle** is a [propelling nozzle](#) (usually of the [de Laval](#) type) used in a [rocket engine](#) to expand and accelerate the [combustion](#) gases produced by burning [propellants](#) so that the exhaust gases exit the nozzle at [hypersonic](#) velocities.

Simply: the rocket (pumps and a combustion chamber) generates high pressure, a few hundred [atmospheres](#). The nozzle turns the static high pressure high temperature gas into rapidly moving gas at near-ambient pressure.

Vacuum use[[edit](#)]

For nozzles that are used in vacuum or at very high altitude, it is impossible to match ambient pressure; rather, nozzles with larger area ratio are usually more efficient. However, a very long nozzle has significant mass, a drawback in and of itself. A length that optimises overall vehicle performance typically has to be found. Additionally, as the temperature of the gas in the nozzle decreases, some components of the exhaust gases (such as water vapour from the combustion process) may condense or even freeze. This is highly undesirable and needs to be avoided.

[Magnetic nozzles](#) have been proposed for some types of propulsion (for example, [Variable Specific Impulse Magnetoplasma Rocket](#), VASIMR), in which the flow of [plasma](#) or ions are directed by [magnetic fields](#) instead of walls made of solid materials. These can be advantageous, since a magnetic field itself cannot melt, and the plasma temperatures can reach millions of [kelvins](#). However, there are often thermal design challenges presented by the coils themselves, particularly if superconducting coils are used to form the throat and expansion fields.

de Laval nozzle in 1 dimension[[edit](#)]

Diagram of a de Laval nozzle, showing flow velocity (v) increasing in the direction of flow, with decreases in temperature (t) and pressure (p).

The Mach number (M) increases from subsonic, to sonic at the throat, to supersonic.

Main article: [De Laval nozzle](#)

The analysis of gas flow through de Laval nozzles involves a number of concepts and simplifying assumptions:

- The combustion gas is assumed to be an [ideal gas](#).

As a note of interest, v_e is sometimes referred to as the *ideal exhaust gas velocity* because it is based on the assumption that the exhaust gas behaves as an ideal gas.

As an example calculation using the above equation, assume that the propellant combustion gases are: at an absolute pressure entering the nozzle of $p = 7.0$ MPa and exit the rocket exhaust at an absolute pressure of $p_e = 0.1$ MPa; at an absolute temperature of $T = 3500$ K; with an isentropic expansion factor of $\gamma = 1.22$ and a molar mass of $M = 22$ kg/kmol. Using those values in the above equation yields an exhaust velocity $v_e = 2802$ m/s or 2.80 km/s which is consistent with above typical values.

The technical literature can be very confusing because many authors fail to explain whether they are using the universal gas law constant R which applies to any [ideal gas](#) or whether they are using the gas law constant R_s which only applies to a specific individual gas. The relationship between the two constants is $R_s = R/M$, where R is the universal gas constant, and M is the molar mass of the gas.

Specific impulse^[edit]

Thrust is the force that moves a rocket through the air or space. Thrust is generated by the [propulsion](#) system of the rocket through the application of Newton's third law of motion: "For every action there is an equal and opposite reaction". A gas or working fluid is accelerated out the rear of the rocket engine nozzle, and the rocket is accelerated in the opposite direction. The thrust of a rocket engine nozzle can be defined as:^{[1][2][4][5]}

and for perfectly expanded nozzles ($p_e = p_o$), this reduces to:

The specific impulse is the ratio of the thrust produced to the weight flow of the [propellants](#). It is a measure of the fuel efficiency of a rocket engine. In [English Engineering units](#) it can be obtained as^[6]

where:

, gross thrust of rocket engine (N)

, mass flow rate of gas (kg/s)

, velocity of gas at nozzle exhaust (m/s)

, pressure of gas at nozzle exhaust (Pa)

, external ambient, or free stream, pressure (Pa)

, cross-sectional area of nozzle exhaust (m^2)
,

, equivalent (or effective) velocity of gas at nozzle exhaust (m/s)
,

, specific impulse (s)
,

, [standard gravity](#) (at sea level on Earth); approximately 9.807 m/s^2
,

In certain cases, where $\gamma = 1$, equals g , the formula becomes

In cases where this may not be so, since for a rocket nozzle $\dot{m} v_e$ is proportional

to $\dot{m} v_e$, it is possible to define a constant quantity that is the vacuum I_{sp} for any given engine thus:

and hence:

which is simply the vacuum thrust minus the force of the ambient atmospheric pressure acting over the exit plane.

Essentially then, for rocket nozzles, the ambient pressure acting on the engine cancels except over the exit plane of the rocket engine in a rearward direction, while the exhaust jet generates forward thrust.



Nozzles can be (top to bottom):

- underexpanded
- ambient
- overexpanded
- grossly overexpanded.

If a nozzle is under- or overexpanded, then loss of efficiency occurs relative to an ideal nozzle. Grossly overexpanded nozzles have improved efficiency relative to an underexpanded nozzle (though are still less efficient than a nozzle with the ideal expansion ratio), however the exhaust jet is unstable.^[7]

Aerostatic back-pressure and optimal expansion[[edit](#)]

As the gas travels down the expansion part of the nozzle, the pressure and temperature decrease, while the speed of the gas increases.

The supersonic nature of the exhaust jet means that the pressure of the exhaust can be significantly different from ambient pressure – the outside air is unable to equalize the pressure upstream due to the very high jet velocity. Therefore, for supersonic nozzles, it is actually possible for the pressure of the gas exiting the nozzle to be significantly below or very greatly above ambient pressure.

If the exit pressure is too low, then the jet can separate from the nozzle. This is often unstable, and the jet will generally cause large off-axis thrusts and may mechanically damage the nozzle.

This separation generally occurs if the exit pressure drops below roughly 30–45% of ambient, but separation may be delayed to far lower pressures if the nozzle is designed to increase the pressure at the rim, as is achieved with the [SSME](#) (1–2 psi at 15 psi ambient).^[8]

In addition, as the rocket engine starts up or throttles, the chamber pressure varies, and this generates different levels of efficiency. At low chamber pressures the engine is almost inevitably going to be grossly over-expanded.

Optimal shape^[edit]

The ratio of the area of the narrowest part of the nozzle to the exit plane area is mainly what determines how efficiently the expansion of the exhaust gases is converted into linear velocity, the exhaust velocity, and therefore the [thrust](#) of the rocket engine. The gas properties have an effect as well.

The shape of the nozzle also modestly affects how efficiently the expansion of the exhaust gases is converted into linear motion. The simplest nozzle shape has a ~15° cone half-angle, which is about 98% efficient. Smaller angles give very slightly higher efficiency, larger angles give lower efficiency.

More complex shapes of revolution are frequently used, such as [bell nozzles](#) or parabolic shapes. These give perhaps 1% higher efficiency than the cone nozzle and can be shorter and lighter. They are widely used on launch vehicles and other rockets where weight is at a premium. They are, of course, harder to fabricate, so are typically more costly.

There is also a theoretically optimal nozzle shape for maximal exhaust speed. However, a shorter bell shape is typically used, which gives better overall performance due to its much lower weight, shorter length, lower drag losses, and only very marginally lower exhaust speed.^[9]

Other design aspects affect the efficiency of a rocket nozzle. The nozzle's throat should have a smooth radius. The internal angle that narrows to the throat also has an effect on the overall efficiency, but this is small. The exit angle of the nozzle needs to be as small as possible (about 12°) in order to minimize the chances of separation problems at low exit pressures.

Advanced designs^[edit]

A number of more sophisticated designs have been proposed for [altitude compensation](#) and other uses.

Nozzles with an atmospheric boundary include:

- [expansion-deflection nozzle](#).^[10]
- [plug nozzle](#).
- [aerospike](#).^{[10][11]}
- [single-expansion ramp nozzle](#) (SERN), a linear expansion nozzle, where the gas pressure transfers work only on one side and which could be described as a single-sided aerospike nozzle.

Each of these allows the supersonic flow to adapt to the ambient pressure by expanding or contracting, thereby changing the exit ratio so that it is at (or near) optimal exit pressure for the corresponding altitude. The plug and aerospike nozzles are very similar in that they are radial in-flow designs but plug nozzles feature a solid centerbody (sometimes truncated) and aerospike nozzles have a "base-bleed" of gases to

simulate a solid center-body. ED nozzles are radial out-flow nozzles with the flow deflected by a center pintle.

Controlled flow-separation nozzles include:

- [expanding nozzle](#),
- bell nozzles with a removable insert,
- [stepped nozzles](#), or dual-bell nozzles.^[12]

These are generally very similar to bell nozzles but include an insert or mechanism by which the exit area ratio can be increased as ambient pressure is reduced.

Dual-mode nozzles include:

- dual-expander nozzle,
- dual-throat nozzle.

These have either two throats or two thrust chambers (with corresponding throats). The central throat is of a standard design and is surrounded by an annular throat, which exhausts gases from the same (dual-throat) or a separate (dual-expander) thrust chamber. Both throats would, in either case, discharge into a bell nozzle. At higher altitudes, where the ambient pressure is lower, the central nozzle would be shut off, reducing the throat area and thereby increasing the nozzle area ratio. These designs require additional complexity, but an advantage of having two thrust chambers is that they can be configured to burn different propellants or different fuel mixture ratios. Similarly, Aerojet has also designed a nozzle called the "Thrust Augmented Nozzle",^{[13][14]} which injects propellant and oxidiser directly into the nozzle section for combustion, allowing larger area ratio nozzles to be used deeper in an atmosphere than they would without augmentation due to effects of flow separation. They would again allow multiple propellants to be used (such as RP-1), further increasing thrust.

Liquid injection thrust vectoring nozzles are another advanced design that allow pitch and yaw control from un-gimbaled nozzles. India's [PSLV](#) calls its design "Secondary Injection Thrust Vector Control System"; strontium perchlorate is injected through various fluid paths in the nozzle to achieve the desired control. Some ICBMs and boosters, such as the [Titan III C](#) and [Minuteman II](#), use similar designs.