

SAN DIEGO STATE UNIVERSITY

V-n Diagram

AE460 Aircraft Design

Greg Marien



- V-n diagrams (speed load factor) defines the strength limitation of an aircraft
 - Every aircraft has their own version
- V-n diagrams are developed during the design process either in the conceptual or very early preliminary design stages
- Four factors affect a V-n Diagram
 - MGTOW
 - Altitude
 - Configuration of aircraft: clean, stores, cruise or landing, etc.
 - Symmetry of loading
- Structural Air Speed Limits, above which may encounter
 - Critical gust
 - Damaging flutter
 - Control/Lift surface reversal
 - Damaging or control-related compressibility effects, i.e. buffets


Development Process Entry Criteria



- Aircraft has many loading conditions to consider. For this class we are only going to consider air loads on the wing, taking into account maneuver and gust loads.
- Entry Criteria
 - Wing loft complete
 - Aero...
 - Mass Properties completed
- Requirements (most aircraft designs will use one of these or something equivalent)
 - SRD for your aircraft
 - MIL-A-8860: Airplane Strength and Rigidity, General Specification for
 - MIL-A-8861: Airplane Strength and Rigidity Flight Loads
 - 14CFR23 (if applicable)
 - 14CFR25 (if applicable)
- Other Good References
 - Bruhn: Analysis and Design of Flight Vehicle Structures
 - Niu: Airframe Structural Design
 - Raymer: Aircraft Design: A Conceptual Approach
 - Roskam: Airplane Aerodynamics and Performance
 - Plenty of other internet sources... Google it.

V-n Diagram¹






¹Aerodynamics for Naval Aviators, NAVWEPS 00-80T-80

MIL-A-8861: V-n Diagram










- Vertical Gusts can cause a rapid increase in AoA
- Use discrete gust formulas (see applicable reference), based on:
 - Altitude
 - Mass Ratio/Gust Alleviation Factor
 - W/S and $C_{L\alpha}$

Reminder:
$$C_{L\alpha}$$
 is a f(M, sweep)

• Use MIL-A-8861 Discrete Gust Analysis or equivalent 14CFR25 for SSBJ

Combined V-n Diagram









- V-n Diagrams for each of the following:
 - lightest weight configuration, at sea level
 - lightest weight configuration, at highest cruise altitude
 - heaviest weight configuration, at sea level
 - heaviest weight configuration, at highest cruise altitude





• Last minute change, no class Thursday.



SAN DIEGO STATE UNIVERSITY