





Introduction • Milk is an easily perishable raw material. • Contaminating bacteria may multiply rapidly and render it unsuitable for processing and/or unfit for human consumption. • Bacterial growth can be retarded by refrigeration and/or heat treatment thereby slowing down the rate of deterioration. Under certain conditions refrigeration may not be feasible due to economical and/or technical reasons. • In India milk is produced in small quantities (2-4) liters by approx. 70 million farmers spread around 5 lakh villages Difficulties in applying refrigeration are specially a problem for certain areas in the country for setting up or expanding milk production. In these situations, it would be beneficial to have access to a method, other than refrigeration, for retarding bacterial growth in raw milk during collection and transportation to the dairy processing plant.










Influence of H₁O₂ on proteins


In higher concentration H₂O₂ oxidizes proteins especially βlactoglobulin, casein, and some enzymes *e.g.*, pepsin, trypsin and chymotrypsin

- Addition of H₂O₂ ≥ 0.02% reduce rennet coagulation properties and thus produce soft curd
- H₂O₂ causes complete breakdown of β -lactoglobulin
- Some essential and non-essential amino acids *e.g.*, tyrosine, tryptophan, cysteine, cystine, lysine and methionine are very sensitive to H₂O₂

Influence of H₂O₂ on fat

• It increases the oxidative rancidity of fat rich dairy products






Immunoglobulins


Antibodies synthesized in response to stimulation by specific antigens
 Offers non-specific humoral immunity response to Gram –ve enteric & respiratory bacteria

Name	Types	Description
IgA	2	Prevents colonization of bacteria
IgD	1	Activate basophils and mast cells to produce antimicrobial factors
IgE	1	Binds to allergens and triggers histamine release from cells and basophiles that involved in allergenic reactions
IgG	4	Provides the majority of antibody-based immunity against invading pathogens. The only antibody capable of crossing the placenta to give passive immunity to fetus.
IgM	1	Eliminates pathogens in the early stages of B cell mediated (humoral) immunity


• Cow colostrum: 40.1 μ g/ 100 g whey protein, Cow milk: 0.45 μ g/100g WP

 Lactoferrin is a Fe-binding globular glycoprot of the immune system of the body It has antimicrobial activity e.g., bacteriostatic fungicide Antimicrobial activity results from its unsatur only 5-30% saturated with Fe and removes Fe Shown to inhibit the grown of food borne pat 	c, bacteriocidal and rated Fe character, as it is from the microbes
 fungicide Antimicrobial activity results from its unsatur only 5-30% saturated with Fe and removes Fe 	rated Fe character, as it is from the microbes
only 5-30% saturated with Fe and removes Fe	from the microbes
• Shown to inhibit the grown of food borne pat	hogens e.g., <i>E. coli & S</i> .
aureus	
Product	mg/ml
Cow milk	0.10
Cow colostrum	0.70
Buffalo coloustrum	0.75
Buffalo milk	0.32
Human milk	10.0
Human colostrum	1.0







E	Effect of Pasteurization on					
antimicrobial components of milk						
MilkComponent	Role in Milk	Effect of Pasteurization				
Bovine immunoglobulins	Transfers immunity against bovine pathogens to calves; may provide some lactogenic immunity to the gut. Most immunoglobulins are carried in colostrum	No loss in activity during batch pasteurization (62.7°C/30min), retains 60- 70% activity after HTST pasteurization				
Lactoferrin	An Fe-binding protein, scavenger of Fe, thereby providing anti-bacterial effects by limiting the availability of free Fe required for bacterial proliferation	Unheated and pasteurized lactoferrin have similar antibacterial properties				
Lysozyme	Active primarily against Gram +ve bacteria. In conjunction with lactoferrin has bactericidal effects	Greater than 75% of activity retained after heating at 80°C/15 sec				





Introduction


- An alternative method for preserving milk would still be of great advantage in certain situations. The search for such a method has therefore continued.
- Interest was focused on combining an indigenous antibacterial systems with very low dose use of chemicals to determine if these could be applied practically to preserve raw milk.
- During the last decade research has demonstrated that one of these systems, the lactoperoxidase/ thiocyanate/ hydrogen peroxide system (LP-system) can be used successfully for this purpose.























Practical Application of the Method

The enzymatic reaction is started in the milk when the hydrogen peroxide (sodium percarbonate) is added. It is completed within about 5 minutes from the addition of H_2O_2 ; thereafter, no hydrogen peroxide is present in the milk.

- The activation of the lactoperoxidase system should be carried out within 2-3 hours from the time of milking.
- Quantities of sodium thiocyanate and sodium percarbonate needed for the treatment of a certain volume of milk, for example 40 or 50 litre, should be distributed to the collecting centre/point in prepacked amounts lasting for a few weeks at a time.

nterval after	TA (%LA)		
nilking (hr)	Control	LP-treated	
4	0.128	0.126	
5	0.135	0126	
6	0.135	0.126	
7	0.135	0.128	
8	0.137	0.128	
9	0.160	0.122	
	(Sl. Sour)		
10		0.122	
11		0.122	
12		0.153 (Sl. Sour)	

Cows milked at 4-6 AM; samples stabilized at 7:30-8:00 AN Temperature 30-32°C						
Test	Treat	-	rcentage	entage sample acceptance at		
	ment	10 AM	12 AM	2 PM	4PM	6PM
Ten min	LP	100	100	70	50	30
resazurin	С	80	60	10	0	0
Acidity* Alcohol stability COB	LP	100	100	80	60	50
	С	70	60	20	0	0
	LP	100	100	90	60	50
	С	70	60	30	10	10
	LP	100	100	100	100	80
	С	100	100	90	30	30
	*Cut o	ff ≥ 0.16%	6 LA			

Microbiological Effects	s &	Performance	of	LP-s
--------------------------------	-----	-------------	----	------

Effectiveness of LP-s depends on three factors: storage temperatures of milk, bacterial cell density & type of organism

. 0	
Temperature (°C)	Time (hrs)
31-35	4-7
30	7-8
25	11-12
20	16-17
15	24-26
4	5-6 days

- LP-s persists only for limited time-period which decreases as the ambient temperature increases
- LP-s relevant to low temperature storage due to the growth of *Pseudomonas* spp. & *Lysteria monocytogenes*
- The efficacy is low at high bacterial concentrations




- The efficacy is low at high bacterial concentrations
- NaSCN : 15 ppm, H₂O₂ 10 ppm
- Addition after 3 hrs of milking
- Incubation temperature 37°C

Bacterial count (SPC/ml)	MBR Time (hrs)
6.7 x 10 ⁶	8.5
6.4 x 10 ⁷	5.0
8.2 x 10 ⁷	3.0


Microbiological Effects & Performance of LP-s


- Antimicrobial activity of LP-s has been demonstrated against a wide range of microorganisms, e.g., bacteria, HIV-1 virus, moulds, yeasts, mycoplasma & protozoa
- Depending upon the bacterial species or even the strain of the microorganism the effect can be bacteriostatic or bactericidal
- LAB: sometimes self-inhibitory, Catalase +ve are not

Impact of LP-s on Some Common Milk-borne Pathogens				
Pathogen	Effect of LP-s	Demonstrated in		
<i>E. Coli</i> including <i>E.</i> <i>Coli</i> 0157:H	Bactericidal	Raw cow milk		
	Reduced gastrointestinal colonization rate of coliform bacteria	Raw cow, goat & camel milk, culture medium and infant formula		
Salmonella typhimurium	Bactericidal & Bactriostatic (depending on No. of mos)	Raw milk		
Salmonella typhimurium & other Salmonella spp.	Bactericidal	Culture medium, infant formula and fresh cheese		
Camphylobactor jejuni	Bactericidal	Cow milk		
Staphyloccus aureus	Bactericidal & Bactriostatic	Cow, goat & camel milk		
Lysteria monocytogenous	Bactericidal & Bactriostatic (Depending on temp., time & strain)	Raw cow & goat milk, UHT milk, soft cheese		
Yersinia enterocolitica	Bactericidal	Cow milk		
Brucella melitensis	Bactericidal	Goat milk		




	t to 8 mg of thiocyanat	e duny)
Time interval (weeks)	Serum thiocyanate level (mg/L) [Non- smokers]	Serum thiocyanate level (mg/L) [Smokers]
0	4.0	8.4
4	7.8*	10.7
8	6.9	10.1
12	7.0*	8.9
	*Significant increase ov	ver initial






Intended Utilization of the Method

- The method should primarily be used to prevent undue bacterial multiplication in raw milk during collection and transportation to the dairy processing plant
- This method should only be used in situations when technical, economical and/or practical reasons do not allow the use of cooling facilities for maintaining the quality of raw milk.
- Use of the LP-system in areas which currently lack an adequate infrastructure for collection of liquid milk, would ensure the production of milk as a safe and wholesome food, which otherwise would be virtually impossible.
- The method should not be used by the individual milk producer but at a suitable collecting point/centre. These centres must be equipped with proper facilities for cleaning and sanitizing the vessels used to hold and transport milk.



Using LP-s for preserving evening milk

- Five times increase in SCN & H₂O₂ (75:50 ppm) increase the keeping quality of raw milk up to 15 hrs
- Upon addition of second dose of H₂O₂ on the 10th hr the keeping quality was increased up to 18 hrs
- The 18 hrs shelf life would permit the collection of evening milk with LP treatment along with untreated morning milk
- Mixing of these two milks at the dairy would bring down the SCN level to the CAC recommended level 15ppm



Current Status There is a codex provision that the LP-s should not be used for products intended for international trade The LP-s is not adopted in the first place in some countries because of a fear of being excluded from international markets. If products treated with the LP-s are not considered suitable for international trade then this raises doubts as to whether it is appropriate and safe to use for milk and dairy products in the domestic market

Indian Scenario

NaSCN : 15 ppm, H₂O₂ 10 ppm, after 3 hrs of milking, incubation temperature 37°C

Trial No.	SPC/ml		MBRT	(hrs)
	Control	Treated	Control	Treated
1	6.8 x 10 ⁶	4.8 x 10 ⁵	6.50	8.5
2	6.4 x 107	9.5 x 10 ⁵	3.50	5.0
3	8.2 x 10 ⁷	2.2 X 10 ⁷	1.75	3.0
4	1.4 X 10 ⁷	7.5 X 10 ⁶	2.0	4.5
Average	2.6 x 10 ⁷	2.9 X 10 ⁶	3.25	5.25

• Samples were taken after one hour of activation of the LP-s

