

Membrane separation

DEPARTMENT OF AGRICULTURAL ENGINEERING, SOABE CENTURION UNIVERSITY OF TECHNOLOGY AND MANAGEMENT PARALAKHEMUNDI, ODISHA



Outline

Ultrafiltration

- Introduction
- Membrane module
- Polymer used in membrane manufacturing
- Fouling of membrane
- UF membrane preparation methods



Uses of membrane filteration

- Changing pattern of milk consumption is stressing on individual use of its components.
- Whey which has high BOD value is being efficiently concentrated form protein. Then, the lactose in the permeate solution can also be handled by RO.
- It saved energy in transportation, due to concentration.
- 4. Cheaper method of drying. Pumping is involved, as against evaporation of moisture.
- 5. Possibility of incorporating whey proteins into cheese.
- Pollution due to whey is controlled, as whey contains lactose.
- Milk also can be concentrated without damage to protein or changing flavour unlike in concentration and drying.
- Other industrial uses, like water purification, fractionation & concentration in Food and Pharmaceuticals, recovery of various components of waste for further use.



Membrane separations




Fig. Types of membrane separations



Membrane: A membrane can be defined as a phase which acts as a barrier to flow of molecular or ionic species between other phases that it separates. It is either dry solid, a solvent swollen gel, or a liquid that is immobilized.

Semipermeable membrane: A membrane which allows some molecules to pass and retains other according to their size.

Composite membrane or thin film: Thin filtering layer built on to the support layer and the two layers are of different materials.

Asymmetric Membrane: Chemically of the same material throughout but physically is of different structure on its two sides.

Membrane cut off: Molecular weight above which 100 % (in practice 95%) of a solute is retained by the membrane.

Permeate: The filtrate, the liquid passing through the membrane.

Concentration Factor: The volume reduction achieved by concentration.

Initial volume of feed Final conc. of component retained



Retention Factor: It specifies the ability of a membrane to retain that molecule.

$$C_f - C_p$$

R= ----- where, C_f = Conc. of molecule in feed

In Batch process where the concentrations are continually changing, R varies and then the realistic value can be,

Ln (C/Co) = R ln (Vo/V) where, Co = Initial concentration at Vo

C = Conc. at any other volume V



Characteristics:

Membrane Asymmetrical

Thickness $150 - 250 \mu m$

Thin film 1 µm

Pore size $0.2 - 0.02 \mu m$

Rejection of Macro molecules, proteins, polysaccharides, vira

Membrane materials Ceramic, PSO, PVDC, CA, thin film

Membrane module Tubular, hollow fibre, spiral wound, plate-and-frame

Operating pressure 1-10 bar

Mechanism of membrane retention Molecular screening

Typical flux $30 - 300 \text{ lit/m}^2\text{h}$



Membrane Modules

- 1. Tubular module
- 2. Hollow fibre
- 3. Spiral wound
- 4. Plate and frame design

Polymers used in membrane manufacturing

- 1. Cellulose acetate
- 2. Polyamide membranes
- 3. Polysulfone membranes
- 4. Ceramic membranes



U.F. membrane preparation methods:

- · Phase inversion
- · Thermal inversion
- Dynamic membrane
- · Ultrathin composite membranes
- · Track etched membranes

Disadvantages:

- As the surface of membrane is not smooth, building of scale leads to idle environment for bacterial growth.
- · The voids provide space for growth of micro-organisms.
- Disassembly of the UF equipment for manual cleaning is not practical due to high surface area involved.



Applications:

- Separation and fractionation of individual milk proteins from lactose and minerals.
- Enzyme recovery in various operations like lactose hydrolysis using lactase.
- Fractionation of cheese whey
- Pre concentration of milk for cheese manufacturing.
- Sugar refining
- Vegetable protein processing. e.g. soy proteins
- 7. Concentration of egg white
- 8. Animal products industry. e.g. gelatin
- 9. Biotechnology applications
- 10. Fruit juices & other beverages.



Thank you